


Product:


# DAS-2A

## Connecting an analog sensor with single-ended output to DAS-2A


Proper connection depends on the internal circuitry of the sensor used.  
Optimum function of the examples below cannot be guaranteed for any individual case.



Analog sensor with 5V supply



Analog sensor with 12V supply



Analog sensor with internal DC-DC converter